

NOTES

Radio

Channel 16 for listening and emergency transmissions.

Communicating with Sector NY

- A) Sector New York, Sector New York, Sector New York, this is (call sign) auxiliary vessel 241467 on 21 Alpha. OVER.
- B) Auxiliary 467 Sector New York. OVER
- A) Conducting man overboard drill at GWB. Ops normal. OVER
- B) OUT

- Pre-Underway Check
- Float Plan
- GAR

GAR report could change over the course of the day depending on the weather.

Coast Guard priorities

- 1) SAVE LIVES
- 2) MINIMIZE PROPERTY DAMAGE
- 3) PROTECT THE ENVIRONMENT

- Do Not jump in the water
- Do Not tie up to a sinking or burning boat
- Keep PIW away from boat until engine is shut off.
-

Nav Rule

When two vessels are bow to bow, turn to starboard to pass port to port
Make your intent known.

Dock your starboard side to a float.

Trimming the motor = lifting it out of the water

Useful Acronyms

PPE: Personal Protective Equipment
PFD: Personal Flotation Device
SOP: Standard Operating Procedure
XO: Executive Officer

PIW: Person in the Water

POB: Persons on Board

Position of 79th Street Boat Basin:

40 degrees, 47 min., 11 sec. N

73 degrees, 59 min., 08 sec. W

* Know how to convert decimals to degrees and seconds and vice versa

Lines and Cleats

How many cleats on a boat? 8

Working turn: “take in the slack on line 4”

Round turn

Make it up: Making up line 4 i.e. figure 8 knot to a cleat.